

# OPERATION

# LEDS

# JAMMAN EXPRESS XT QUICK START

1

## RECORD

PRESS FOOTSWITCH  
ONCE



REC

2

## PLAY

PRESS FOOTSWITCH  
ONCE



PLAY

3

## OVERDUB

PRESS FOOTSWITCH  
ONCE



DUB

4

## UNDO/REDO

WHILE PLAYING, PRESS  
& HOLD FOOTSWITCH



DUB

5

## STOP

PRESS FOOTSWITCH  
TWICE



REC

DUB

PLAY

6


## CLEAR

WHILE STOPPED, PRESS  
& HOLD FOOTSWITCH



REC

# HOOKUP DIAGRAM



**NOTE:** For best noise performance, use an isolated power supply.